



SECU Truck CONTROL

SECU Truck Control



Theft Control System (SPD) for control of several different sensor-inputs and sensor-outputs covering

- Alarm mails for unauthorized accesses
- Coded unloadings
- SECU App – Data Management Program

Tracking
Mapping
Alarm-Mailing
Geo-Fencing

SECU Truck Control TC-Main, TC-In, TC-Out



SECU Truck Control TC-Main includes:

- 4 inputs and 2 outputs
- Integrated GPS
- Integrated Back-Up Battery
- Keyboard for code entry

SECU Truck Control TC-In includes additionally up to 64 inputs and up to 16 analog inputs.

SECU Truck Control TC-Out includes additionally up to 40 outputs and up to 8 analog outputs.

SECU Truck Alarm




The location of the tanker-truck is displayed on a digital map.

Indications and Events are shown in „red“ or „green“.

On the left side the events and the location of the tanker-truck are shown in real time.

Alarms are generated automatically in case of a wrong position or of a non authorized access.

View History



In „View History“ the complete history of a tanker-truck is displayed and related events shown in real time and location on the digital map.

The User is able to look into the past and evaluate tours, events or unauthorized accesses with time-stamp and location.

The amount of events shown back into the past is not limited.

Tracking and Mapping



All tanker-trucks and markers in the system can be live tracked on a digital map.

Tanker-trucks with problematic status are displayed in „red“ and immediate alarm mails are sent to defined email-addresses.

In that way the User is immediately and everywhere informed about the status and condition of his tanker-trucks.

Different Sensors



Man Lid Sensor

Different kinds of sensors can be connected to SECU Truck Control.....



Cabinet Box Sensor

SECU Truck Control TC-Main, TC-In, TC-Out



- Up to 64 + 4 Sensor Inputs (TC-Main + TC-In)
- Up to 40 + 2 Outputs (TC-Main + TC-Out)
- Up to 16 Analog Inputs 4-20mA/0-5V (TC-InA)
- Up to 8 Analog Outputs 4-20mA/0-5V (TC-OutA)
- Data Transfer to on-board-PC
- SECU-App (Data Management Program with Tracking/
Mapping/Alarm-Mailing/Geo-Fencing)
- Cabinet-Box Control
- Man-Lid Control
- Control of bottom valves and APIs
- Integrated Back-Up Battery
- Keyboard for coded unloadings
- Integrated GPS
- EX- and Non-EX Applications